



CPR

COLD POUR RUBBER

POT-HOLE REPAIR KIT

INSTRUCTIONS



1 PREPARE



2 OPEN



3 MIX



4 POUR

MAKE SURE TO FOLLOW MIXING AND APPLICATION INSTRUCTIONS CAREFULLY FOR OPTIMAL PERFORMANCE!

1. Remove the contents of the bucket.
2. Shake **Part A** for 10 seconds until the tan liquid disappears, then pour it into the bucket.
3. Cut open the **Part B** aggregate sand so that it can be poured into the bucket.
4. After all of the aggregate sand and liquid are in the bucket, use a mixing drill and paddle and mix for **30 seconds** until the product is uniform.

After mixing for 30 seconds, **immediately** pour the mixture into the hole until it is level or slightly above level. The patch will self-level.